



## HANDRAIL MINDER INSTALLATION PROCEDURE

### Tools:

Safety glasses or goggles

Electric drill

Phillips type driver bit

Marking pen

Small bottle of Loctite Threadlocker or other retaining compound



### Procedure:

1. Place the Handrail Minder in the desired location on the top of the handrail.
2. Mark the hole locations for installation.
3. The screws that are supplied with your Handrail Minders are self-drilling and self-tapping screws. All you need to do is line up the screw with the marks and drive them in. Do this with the Handrail Minder in place.
4. After the screw is in, back it out a few rotations and apply a drop or two of Loctite on the threads and then drive the screw back into place. The Loctite is necessary to make the installation permanent so that vandals cannot remove the piece.
5. Space your next Handrail Minder approximately 3-4 feet from the first one and repeat the process.