



GRINDTOAHALT.COM

PO BOX 221 | ELBURN, IL 60119 | P 630.365.2375 | F 630.365.1075

BOLT-ON GRINDERMINDER INSTALLATION INSTRUCTIONS:

Tools Needed:

- Drill
- Drill Bit, size: 7/16"
- Loctite™ Threadlocker (This product is designed for the locking and sealing of threaded fasteners which require normal disassembly with standard hand tools. The product cures when confined in the absence of air between close fitting metal surfaces.)

1. Drill a 7/16" hole through the surface on which the GrinderMinders will be installed.
2. Turn the GrinderMinder upside down so that the hole is exposed. Put 2-3 drops of Loctite on the threads in the hole.
3. Insert the bolt with the washer upwards through the underside of the surface.
4. Line the hole of the GrinderMinder up with the threads of the bolt and screw into place.

